



## SONY ID CARD PRINTER RIBBON CROSS-REFERENCE GUIDE

### CIM®, Cimage K-Series 300, 400, 500 & 600

Color Panels	Number of Prints	Replaces CIM Part Number	Sony Item #
YMCKO	200	NC900KCC411	17227591
YMCKO	350	NC900KRC411A	17227845
YMCKK	200		17230483
YMCKOK	170		17230564
YMCKOK	250		17230575
KO	600		17229364
K (Black Resin)	1000	NC900KRCA01	17227993
K (Black Resin)	1500		17230346

### DataCard®, Image Card® II,III,IV, Express, S2, Ultima, Select & Magna \*Extra Length Ribbon for use in ImageCard IV

Color Panels	Number of Prints	Replaces DataCard Part Number	Sony Item #
YMCK	165	806124-102	17229135
YMCK-T	135	806124-104	17229308
YMCK-T*	500	806124-404	17230335
KT-YMCT	110	806124-107	17230313
KT-YMCKT	95	806124-106	17230324
T(Topcoat)	420	806125-103	17229146
K (Black Resin)	900	596230-001	17227580
Cleaning Tape	750	557575-001	17290004

### Eltron® P-300, P-310F, P-310, P-400, P-420, P-500, P-600 \*Extra length ribbon for use in P-310 & P-420 Card Printers

Color Panels	Number of Prints	Replaces Eltron Part Number	Sony Item #
YMCK	250	800015-145	17230612
YMCKO	200	800015-140	17227591
YMCKO*	350	800015-340	17227845
YMCKK	200	800015-180	17230483
YMCKOK	170	800015-148	17230564
YMCKOK*	250	800015-348	17230575
KO	600	800015-160	17229364
K (Black Resin)	1000	800015-101	17227993
K (Black Resin)	1500	800015-301	17230346

### Magicard® Turbo and Turbo Flip

Color Panels	Number of Prints	Replaces Magicard Part Number	Sony Item #
YMCKO	250	UR1	17227616
K (Black Resin)	1000	UR-3	17237088

### Nisca® PR5100, PR5200, PR5300

Color Panels	Number of Prints	Replaces Nisca Part Number	Sony Item #
YMCKO	250	3885YMCKO	17230021
K (Premium Resin)	1250	BLK	17230020
YMCKOK	210	3885YMCKOK	17230031

### NBS® Impressions Series®

Color Panels	Number of Prints	Replaces NBS Part Number	Sony Item #
YMCKO	200	78046500	17227591
K (Black Resin)	1000	78047700	17227993

### Polaroid® 75 & 100

Color Panels	Number of Prints	Replaces Polaroid Part Number	Sony Item #
YMCKO	350		17227845
YMCKOK	170		17230564
YMCKOK	250		17230575
KO	600		17229364
K (Black Resin)	1500		17230346

Find your brand of card printer, then find your printer model. Next to it you'll see the manufacturer's part numbers for appropriate ribbons, and the corresponding Sony part numbers. Use these Sony part numbers to order the appropriate Sony ribbons for your printer. Remember, we guarantee complete OEM compatibility.

**SONY**  
**SMARTERBETTERCOLOR**

Sony Chemicals Corporation

#### Sony Chemicals Corporation of America

1001 Technology Drive  
Mt. Pleasant, PA 15666-1766  
Phone: (724) 696-7500  
FAX: (724) 696-7555  
E-mail:

sales\_marketing@sonychemicals.com  
www.sonychemicals.com

